

DVD HOME THEATER SYSTEM




















OWNER'S MANUAL



Important Safety Instructions



WARNING: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER-SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

WARNING:TO PREVENT FIRE OR SHOCK

HAZARD, DO NOT EXPOSETHIS APPLIANCE TO RAIN OR

MOISTURE.

CAUTION: TO PREVENT ELECTRIC SHOCK,

MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.



The lightning flash with an arrowhead symbol, within the equilateral triangle, is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to cause an electric shock.




The exclamation point within the equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in this owner manual.

CAUTION INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED. **AVOID EXPOSURE TO BEAM**



product This contains a low power laser device.



On Placement

- · The apparatus shall not be exposed to dripping or splashing.
- Do not use the Unit in places which are extremely hot, cold, dusty, or humid.
- Place the Unit on a flat and even surface.
- Do not restrict the air flow of the Unit by placing it in a place with poor air flow, by covering it with a cloth, or by placing it on carpeting.

FCC Information

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesirable operation.

On Safety

- When connecting or disconnecting the AC cord, grip the plug and not the cord itself. Pulling the cord may damage it and create a hazard.
- When you are not going to use the Unit for a long period of time, disconnect the AC power cord.

· When left in a heated room where it is warm and damp, water droplets or condensation may form inside the Unit. When there is condensation inside the Unit, the Unit may not function normally. Let the Unit stand for 1 to 2 hours before turning the power on, or gradually heat the room up and dry the Unit before use.

- Should any trouble occur, disconnect the AC power cord and refer servicing to a qualified technician.
- Do not place anything directly on the top of the Unit. Damage to the Unit can result.

Notes on Copyright

It is forbidden by law to copy, broadcast, show, broadcast on cable, play in public, rent copyrighted material

Apparatus Claims of U.S. Patent Nos. 4,631,603; 4,577,216; 4,819,098 and 4,907,093 licensed for limited viewing uses only.

DVD video discs are copy protected, and any recordings made from these discs will be distorted. This product incorporates copyright protection technology that is protected by method claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only, unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.








- Read Instructions All the safety and operating instructions should be read before the appliance is operated.
- 2. Retain Instructions The safety and operating instructions should be retained for future reference.
- 3. Heed Warnings All warnings on the appliance and in the operating instructions should be adhered to.
- Follow Instructions All operating and use instructions should be followed.
- 5. Water and Moisture The appliance should not be used near water for example, near a bathtub, washbowl, kitchen sink, laundry tub, in a wet basement, or near a swimming pool, and the like.
- Carts and Stands The appliance should be used only with a cart or stand that is recommended by the manufacturer.
- 6A. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the appliance and cart combination to overturn.



- Wall or Ceiling Mounting The appliance should be mounted to a wall or ceiling only as recommended by the manufacturer.
- 8. Ventilation The appliance should be situated so that its location or position does not interfere with its proper ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation openings; or, placed in a built-in installation, such as a book case or cabinet, that may impede the flow of air through the ventilation openings.
- **9. Heat** The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- 10. Power Sources The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
- 11. Grounding or Polarization Precautions should be taken so that the grounding or polarization means of an appliance are not defeated.
- 12. Power-Cord Protection Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
- 13. Cleaning The appliance should be cleaned only as recommended by the manufacturer.
- **14. Power Lines** An outdoor antenna should be located away from power lines.
- 15. Outdoor Antenna Grounding If an outside antenna is connected to the receiver, be sure the antenna system is grounded so as to provide some protection against voltage surges and built up static charges. Section 810 of the National



Electrical Code, ANSI/NFPA No. 70, provides information with respect to proper grounding of the mast and supporting structure, grounding of the lead-in wire to an antenna discharge unit, size of grounding conductors, location of antenna-discharge unit, connection to grounding electrodes, and requirements for the grounding electrode. See Figure 1.

- 16. Nonuse Periods The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
- 17. Object and Liquid Entry Care should be taken so that objects do not fall, and liquids are not spilled, into the enclosure through openings.
- **18. Damage Requiring Service** The appliance should be serviced by qualified service personnel when:

 A. The power-supply cord or the plug has been damaged; or
 - B. Objects have fallen, or liquid has been spilled, into the appliance; or
 - C. The appliance has been exposed to rain; or
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or E. The appliance has been dropped, or the enclosure damaged.
- 19. Servicing The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.





Table of Contents

Important Safety Instruction	1-2
Disc Formats	4
Before You Start	5
Using the remote control	5
Parts and Functions	
Front Panel	
Rear Panel	
Remote Control	8-9
Display	10
Front Panel Display	
Display Information	
Setup	
For better reception	
Connecting a TV	
Connecting a VCR	
Connecting another source	
Connecting the speakers & subwoofer	
Positioning the speakers and subwoofer	
Mounting rear surround speakers	
Turning on the Unit and TV	16
Power cord connection	16
Adjusting the Sound	
Playing a Disc	
Playing Disc	
Pausing playback (still mode)	
Stopping playback	
To skip to a different track	
Fast Foward/Fast Reverse	
Slow-motion play	
Skip (Forward/Reverse)	
Zooming into an image	
Angle selection	
Audio selection	
Subtitle selection	
Special Functions	23-25
Display function (DVD)	
Locating a specific title	24
Locating a specific title/chapter/track	24
Locating a specific time	25
Angle setting	25
Audio setting	25
Subtitle setting	25
CD/DVD programmable memory	26
DVD programmable memory	26
Title/Chapter programmed playback	26
CD programmable memory	
Track programmed playback	26

Repeat Playback	. 27-28
Repeating a title/chapter (DVD)	27
Repeating a single track/whole disc (CD)	27
Repeating a specific section (DVD)	28
Playing MP3 and Picture File Disc	. 29-30
Playing a MP3 file disc	29
Playing a Picture file disc	
Playing a MP3/Picture file disc	
Radio Operation	31
Tuning into a station manually	31
FM Stereo	31
Weak FM stations	31
To search for a station automatically	31
Presetting stations	31
Tuning into a preset station	31
Customizing the Function Settings	32-40
LANGUAGE setting	32
VIDEO setting	33
TV Shape	33
Video Output	34
Brightness	34
Edges	35
AUDIO setting	36
Digital Out	36
L/R speaker	36
Subwoofer	37
Surround Delay	37
Center Delay	
Pink noise	38
RATING setting	
Password/Parental Lock	39
Factory Set	40
Language Code List for Disc Language	41
Maintenance	42
Cleaning Disc	
Cleaning the Unit	42
Important Note	42
Trouble Shooting Guide	. 42-43





The Unit can playback.



DVDs [12cm(5") disc]



CD-R CD-RW
Compatible



Audio CDs [12cm(5") disc]



Region Management Information

Region Management Information: This Unit is designed and manufactured to respond to the Region Management Information that is encoded on DVD discs. If the Region number printed on the DVD disc does not correspond to the Region number of this Unit, this Unit cannot play that disc.

The region number of this Unit is 1.



Disc Function or Operation that is Not Available

When the symbol appears on the TV screen, it indicates that the function or operation attempted is not available at that time. This occurs because the DVD disc manufacturer determines the specific functions. Certain functions may not be available on some discs. Be sure to read the documentation provided with the DVD.

Icons Used on DVDs

Sample Icons




Notes:

- This Unit supports 2-channel (L/R) audio and 5.1ch (Multi-channel) MPEG Audio 1/2 (only when the DIGITAL AUDIO OUT coaxial jack is used for connection). It does not support 7.1 channel MPEG Audio Version 2.0.
- When playing back a CD-G (Graphics) or CD EXTRA disc, the audio portion will be played, but the graphic images will not be shown.

Title, Chapter and Tracks

 DVDs are divided into "titles" and "chapters". If the disc has more than one movie on it, each movie would be a separate "title". "Chapters" are sections of titles.



 Audio CDs are divided into "tracks". A "track" is usually one song on an Audio CD.



Note:

 Numbers identify each title, chapter, and track on a disc. Most discs have these numbers recorded on them, but some do not.

Notes on Unauthorized Discs

You may not be able to play back some DVD discs on this Unit if they were purchased from outside your geographic area or made for business purposes.

E - 4




Using the Remote Control

- Point the Remote Control at the REMOTE SENSOR located on the Unit.
- When there is a strong ambient light source, the performance of the infrared REMOTE SENSOR may be degraded, causing unreliable operation.
- The recommended effective distance for remote operation is about 16 feet (5 meters).

To install Batteries

1. Open the battery door.







Battery Replacement

When batteries become weak, the operating distance of the Remote Control is greatly reduced and you will need to replace the batteries.


Notes:



- If the Remote Control is not going to be used for a long time, remove the batteries to avoid damage caused by battery leakage corrosion.
- Do not mix old and new batteries. Do not mix ALKALINE, standard (CARBON-ZINC) or rechargeable (NICKEL-CADMIUM) batteries.



Front Panel



1) 5 Disc tray

Open or close tray by pushing
OPEN/CLOSE button. Place discs on the disc trays, label side up.

2) STANDBY indicator

When the Unit is turned on by pressing the \dot{I} / \dot{O} power button, the light will illuminate. If you press the Standby/On button on the remote control, the Unit will turn on.

3) I/ む button

Turn the power on or off.

4) FUNCTION button

Select the source.

5) ■ STOP/BAND button

Stop playing a disc./Switch between AM or FM.

6) ► PLAY/PRESET button

Press to start or resume playback. / Preset Tuner memory up.

7) ◄ SKIP/TUNING ▶ buttons

Press SKIP/TUNING i◀ button to go back to previous chapters/tracks.

Press SKIP/TUNING ➤ button to advance to chapters /tracks. Press and hold ≤ SKIP/TUNING ➤ button to begin fast scan. Four speeds are available. Scan all available radio stations.

8) VOLUME -/+ buttons

Change the loudness of the sound from the speakers connected to the Unit.

9) Remote sensor

Accept the remote control unit signals.

10) DIGITAL indicator

When DOLBY DIGITAL sound is selected, the light will illuminate.

11) I PRO LOGIC I indicator

When DOLBY PRO LOGIC sound is selected, the light will illuminate.

12) Display window

Display system information.

13) DISC SKIP button

To change next available disc.

14) OPEN/CLOSE button

Use to open and close the disc tray.


Note:

Screen saver - If no button is pressed within 3 minutes, the screen save function will activate, If you want to return to the normal screen, press any button.





Rear Panel




- 15) Power cord
- 16) Right FRONT speaker terminals
- 17) Right REAR speaker terminals
- 18) SUBWOOFER terminals
- 19) Center speaker terminals
- 20) Left REAR speaker terminals
- 21) Left FRONT speaker terminals
- 22) DIGITAL AUDIO OUT jack
- 23) AUDIO OUT (L/R) jacks

- 24) S-VIDEO (DVD) output jack
- 25) FM ANTENNA jacks
- 26) AM LOOP ANTENNA terminal
- 27) AUDIO IN (L/R) jacks
- 28) VIDEO IN (VCR) jack
- 29) COMPONENT VIDEO jacks (Y, PB/CB, PR/CR)
- 30) VIDEO OUT jack





Remote Control



1) STANDBY / ON button

Turns the Unit on and puts it in standby mode.

2) RETURN button

Return to the normal operation after using the SETUP menu.

3) Number (0 - 9) and (+10) buttons

Use when creating programs, and entering a parental level password. To select numbers over 9, press +10 button and then the second no. for example, to enter 18, press +10 and then 8.

4) 5.1 / 2.1 CHANNELS button

Switch speaker output to 5.1 channel mode. (All speakers + subwoofer)

Switch speaker outputs to 2.1 channel. (Front left/right speakers + subwoofer)

5) MEMORY button

Enter the number of a selected chapter or track. Enter the number of a selected station.

6) DIMMER button

Adjust the brightness of the front panel display to the level you prefer.

7) DI PRO LOGIC II button

In AV_IN mode, switches to Dolby Pro Logic mode for VHS tapes encoded with Dolby Pro Logic.

8) VOLUME (+/-) buttons

Adjust the volume.

9) SETUP button

Selects the SET UP menu screen.

10) ▼ / ▲ CURSOR buttons

Use to highlight selections on a menu screen and adjust certain settings.

11) ◀I SLOW button

Perform slow reverse playback of DVDs.

12) ◀◀ TUNING ▶▶ buttons

◄: Fast reverse playback.

▶►: Fast forward playback.

◄◄ TUNING ▶▶: Scan all available radio stations.

13) ■ STOP button

Stop playback.

14) I◀ PREV button

Move reverse through titles, chapters or tracks on a disc.

Tune to the presetted stations.

15) CLEAR button

Clear input selections and cancel certain playback functions.

16) DISPLAY (DISP) button

Change disc status information displayed on the TV.

17) ANGLE button 🖰

Switch the camera angle of the video presentation when scenes with multiple camera angles are recorded on a DVD.


18) SUBTITLE button

Select one of the subtitle languages programmed on a $\ensuremath{\mathsf{DVD}}.$

E - 8



Remote Control



19) FUNCTION button

Display the FUNCTION screen where you can check or change various setting.

20) OPEN / CLOSE button

Use to open or close the disc tray.

21) GOTO button

Skip directly to a specific location on a DVD disc.

22) P. SCAN / CVBS button

Changing YUV output to Progressive Scan Video mode.

23) SOUND button

Selects sound balance and tone controls for adjustment with the cursor buttons.

24) DISC 1 - 5 select buttons

25) ◀/▶ CURSOR buttons

Use to highlight selections on a menu screen and make adjust certain settings.

26) MENU button

Open and close DVD's menu.

27) ENTER button

Confirm selections on a menu screen.

28) SLOW I► button

Perform slow forward playback of DVDs.

29) PLAY button

Start playback.

30) II PAUSE button

Pause playback, frame advance.

31) NEXT ►► button

Move forward through titles, chapters or tracks on a disc.

Tune to the presetted stations.

32) ZOOM button

Zoom into an image.

NTSC/PAL button

Select whether to output the video signal.

33) AUDIO button

Select one of the audio soundtracks programmed on a DVD or selects the audio output mode on a AUDIO CD.

34) BAND/REPEAT-DISC button

Switch between AM or FM.

Repeat chapter or title of a DVD.

Repeat single track or whole CD.

35) FM MODE / REPEAT A - B button

Set FM MODE to FM STEREO for FM stereo sound or to FM MONO for mono sound.


Perform point-to-point repeat playback on a DVD or CD.

E - 9



Display

Front Panel Display



Display Information

The DVD displays the information shown below on the TV screen and on the Unit's DVD display depending on the operation status.

Display Examples

	TV Screen	Unit Display	Remarks			
If no disc is loaded when the Main Unit is switched on.	No Disc	поліѕс	"ทิติมิริธ์" appears when the tray is closed and: 1)There is no disc in the tray. 2)The disc type is not playable in this Unit. 3)The disc is not loaded correctly (upside-down, etc.)			
Tray open	<u>*</u>	ОРЕП				
Tray closed		CLOSE				
Loading	O Loading	LOAI				
Stopped	■ Stop	`I \' I	The display changes to show			
Playing	Play ▶		other indicators.			
Paused	Pause II		Freezes the image on the screen or pauses audio playback.			
Fast forward	▶► x 2		The display changes to show other indicators.			
Fast reverse	◄ ◀ x 2		The display changes to show other indicators.			
Slow	- - √ I / I ► x 1/2		Does not function for Audio CDs.			
Repeat A - B	Rep A- Rep A-B	HB	Repeat a specific section.			
	\oslash		The operation is not permitted by the DVD Unit or the			

Region (Local) Number Error Indicator

If the region (local) number of the disc that you attempt to play differs from the region number of the Unit, "Invalid Region" appears on the TV screen. (The disc cannot be played).



4/24/2004, 11:53 AM








For better reception

FМ

Connect FM antenna (included) to the FM ANTENNA jacks.

ΑM

Connect the loop antenna (included) to the AM LOOP ANTENNA terminals.




A.Connecting a TV

The Unit can be connected to your TV in several different ways, depending on the design of your TV.

RCA Audio/Video Jacks

Use the supplied Audio/Video cable.

 $1. \ \ Connect the \ \ VIDEO \ OUT \ and \ left/right \ AUDIO \ OUT \ jacks \ to \ the \ \ VIDEO \ IN \ and \ left/right \ AUDIO \ IN \ jacks \ on \ your \ TV.$



Note:


If you want the sound come from the speakes of the Main Unit, you need not to connect the left/right AUDIO OUT jacks from the Main Unit to your TV.

or

S-Video Jack

Use an S-Video cable (not supplied) and the Audio cable (not supplied).

- 1. Use an S-Video cable to connect the S-VIDEO (DVD) jack on your Unit to the S-VIDEO IN jack on your TV.
- 2. Use the Audio cable to connect the left/right AUDIO OUT jacks on the unit to the left/right AUDIO IN jacks on your TV.











oı

Component video outputs (DVD)

Some TVs or monitors are equipped with component video inputs.

Using the Audio cable (not supplied), connect the left/right AUDIO OUT jacks on your Unit to the left/right AUDIO IN jacks on your TV and the Component video cable (not supplied), connect the **Green** plug **Y** VIDEO OUT jack on your Unit to **Y** VIDEO IN jack on your TV, the **Blue** plug **PB/CB** VIDEO OUT jack on your Unit to **PB/CB** VIDEO IN jack on your TV and the **Red** plug **PR/CR** VIDEO OUT jack on your Unit to **PR/CR** VIDEO IN jack on your TV to view the higher quality picture playback.

Progressive outputs (DVD)

Some TVs or monitors are equipped with component video inputs that are capable of reproducing a progressively scanned video signal.


Using the Audio cable (not supplied), connect the left/right AUDIO OUT jacks on your Unit to the left/right AUDIO IN jacks on your TV and the Component video cable (not supplied), connect the **Green** plug **Y** VIDEO OUT jack on your Unit to **Y** VIDEO IN jack on your TV, the **Blue** plug **PB/CB** VIDEO OUT jack on your Unit to **PB/CB** VIDEO IN jack on your TV and the **Red** plug **PR/CR** VIDEO OUT jack on your Unit to **PR/CR** VIDEO IN jack on your TV to enjoy highest quality picture with less flicker.

Connect the component video cable to TV, press **SETUP** button and select Video Output to YUV (see page E-34 for setting of Video Output). To select the output signal for better picture quality, press the **P. SCAN** button on the remote control when DVD is stopped.

Notes:

- When progressive output is activated, no video signal output from S-video and RCA (CVBS) video jacks.
- Make sure your TV supports progressive scan component video signal, press the P. SCAN button twice until "CVBS" display for going back CVBS video signal.





Audio cable (not supplied)

or

Coaxial Antenna Jack

Some TVs do not have an RCA or S-Video jack, they only have a coaxial antenna jack. In order to connect this Unit to these TVs, you must purchase an RF modulator (available in the Audio/Video department of most electronics retailers or at http://www.18002526123.com) and follow the instructions included with it.

Notes :


- Connect the Unit to your TV directly. If you connect the Unit through a VCR, the playback picture will be distorted because DVD discs are copy protected.
- When you connect the Unit to other equipment, be sure to turn off the power and unplug all of the equipment from the wall outlet before making any connection.
- · Refer to the instruction manual of the connected equipment as well.





B. Connecting a VCR

- 1. Using the supplied Audio/Video cable, connect the yellow plug from VIDEO OUT jack on your Unit to VIDEO IN jack on your TV, connect the left/right AUDIO OUT jacks on your Unit to left/right AUDIO IN jacks on your TV. If you want the sound come from the speakers of the Main Unit, you need not to connect the left/right AUDIO OUT jacks from the Main Unit to your TV.
- Using the Video cable (not supplied), connect the VIDEO IN (VCR) jack on your Unit to VIDEO OUT jack on your VCR.
- 3. Using the Audio cable (not supplied), connect the left/right AUDIO IN jacks on your Unit to the AUDIO OUT jacks on your VCR.
- An adaptor can be bought locally to connect the round RCA-style plugs to a socket. For the TV get a scart INPUT adaptor. For the VCR get a scart OUTPUT adaptor.



To hear the sound from television programmes through the Unit

Sound from the television does not go to the speakers of the DVD amplifier Unit with the suggested connections. To hear sound from television programmes through the DVD amplifier's loudspeakers you need to use your video recorder as a television tuner. To do this follow these steps:

- 1. Connect up the VCR as above in "Connecting a VCR". If your television does not have the round (RCA-style) connectors you can get an RCA to scart input adapter.
- 2. Press the **FUNCTION** button on the DVD Amplifier Unit to get AV_IN mode, shown on the front panel display.
- 3. On the television, select the AV or scart input channel for the DVD amplifier Unit.
- 4. On the VCR, select the television programme you want to watch.
- 5. On the DVD amplifier Unit select normal stereo or Pro Logic decoder modes according to your preference.
 - Please refer to the AV_IN rows of the table on page 18 describing which speakers the sound will come out of.
 - When using the VCR as a television tuner, you cannot watch one programme while recording another.

Watching a DVD

- 1. Turn on the Unit, use the **FUNCTION** button on the remote control or the front panel to select "DVD".
- 2. Turn on your TV and follow the instructions included with it to select the VIDEO input which corresponds to the VIDEO IN jack that is connected to the Unit.

Watching a Videotape

- 1. Turn on the Unit, use the **FUNCTION** button on the remote control or the front panel on the front panel to select "AV_IN".
- Turn on your TV and follow the instructions included with it to select the VIDEO input which corresponds to the VIDEO IN jack that is connected to the Unit.
- 3. Turn on the VCR and follow the instructions included with it to play the videotape.

Note:

- When playback VCR, if you want the sound comes from the speakers (supplied), you need not to connect the Video cable.
- If VCR Audio is mono, surround speakers sound level will be low.

(continued to next page)

4/26/2004, 11:06 AM





Setup

C. Connecting another source

Analogue connection


Using the Audio cable (not supplied), connect the left/right AUDIO OUT jack on your Unit to the AUDIO IN jack on the other analogue equipment.

Digital connection

Using the Coaxial Digital Audio cable (not supplied), connect the DIGITAL AUDIO OUT on your Unit to the DIGITAL AUDIO IN jack on your another equipment.

Listening to another audio equipment

- 1. Turn on the Unit.
- 2. Turn on your audio equipment and follow the instructions included with it to select the AUDIO IN or DIGITAL IN function.







Notes:


- · When you connect the Unit to other equipment, be sure to turn off the power and unplug all of the equipment from the wall outlet before making any connection.
- If the external equipment is a television and this audio system is closed to it, you may experience interference if the tuner function is selected while the television is working.
- When you have selected TUNER function, sound will ONLY come from the front left, right speakers and subwoofer.
- If you have a stereo VCR, make sure you set it in stereo mode.
- Due to copyright protection, DVD movies cannot be copied. If you copy a DVD movie onto a videotape, the resulting copy will be unclear, with poor sound quality. This is NOT caused by a defective DVD system.
- Refer to the instruction manual of the connected equipment as well.





D. Connecting the speakers & subwoofer

- The speaker cords have been color-coded to simplify connection. Just plug the POSITIVE (+) and NEGATIVE (-)
 ends of each speaker wire into the corresponding jacks on the rear of the Unit, matching the color tube on the end
 of the speaker wire to the color-coded connector.
- 2. The front left/right and rear left/right speakers are all the same. However, make sure you connect to the center speaker which is slightly longer than the rest.









Setup

E. Positioning the speakers and subwoofer



Mounting rear surround speakers

- 1) Mark the correct mounting position on the wall.
- 2) Insert a fixing screw(s) at the marked position on the wall.
- Align the slot hole(s) of the speaker over the screw and pull the speaker downward until it is firmly hooked.





Need More Help?

DO NOT RETURN THIS TO THE STORE

Please call Customer Service at 1-800-252-6123

or visit online help at http://www.18002526123.com

Turning on the Unit and TV

- 1)Press the I / & power button to turn the Unit ON, or
- 2)Press the **STANDBY/ON** o button on the remote control or the **FUNCTION** button or the **PLAY** button to turn on the Unit while the Unit is in standby mode.
- 3)Turn on the TV by pressing its POWER button.
- 4)Select the channel on your TV corresponding to the VIDEO IN jack that the Unit is connected to. See TV User guide for more information.
 - If you have connected the Unit successfully, the DVD logo (start-up picture) will appear on your TV screen.

Note:

- Whenever no disc or disc stop for about 30 minutes, the system will be turned to POWER standby mode automatically.
- The green LED of Standby will be turned on while the unit is at standby mode.

Power cord connection

- Make sure that all the components and speakers are connected correctly.
- To prevent electrical shock, match wide blade of plug to wide slot, fully insert.
- Be sure the AC power cord is disconnected and all functions are off before making connections.
- When you are not going to use the Unit for a long period of time, disconnect the power cord.


F - 16

(continued to next page)

VIDEO







To adjust the surround sound balance while Dolby Digital and Pro Logic II decoding is in

Use the remote control to make the following changes to speaker balance:

Front speaker (left)

 Press the SOUND button repeatedly to display LEFT, then press the ▼ or ▲ CURSOR button to adjust the sound level. It will show on the display of the Unit.

Front speaker (right)

 Press the SOUND button repeatedly to display RIGHT, then press the ▼ or ▲ CURSOR button toadjust the sound level. It will show on the display of the Unit.

Center speaker

 Press the SOUND button repeatedly to display CENTR, then press the ▼ or ▲ CURSOR button to adjust the sound level. It will show on the display of the Unit.

Rear speaker (left)

 Press the SOUND button repeatedly to display REARL, then press the ▼ or ▲ CURSOR button to adjust the sound level. It will show on the display of the Unit.

Rear speaker (right)

 Press the SOUND button repeatedly to display REARR, then press the ▼ or ▲ CURSOR button to adjust the sound level. It will show on the display of the Unit

Subwoofer

 Press the SOUND button repeatedly to display SUB, then press the ▼ or ▲ CURSOR button to adjust the sound level. It will show on the display of the Unit.

Note:

• If you do not press any button within a few seconds, the display will return to normal.

To adjust the sound quality

Press the SOUND button repeatedly to select an equalization mode (BASS and TREBLE). Press the ▼ or ▲ CURSOR button to adjust the sound level


BASS: the low range of sounds

TREBLE: the high range of sounds

Bass and treble control the sound from the front left and right speakers.

Dolby Digital

Dolby Digital is a sound system developed by Dolby Laboratories Inc. that gives movie theatre ambience to audio output when the Unit is connected to a Dolby Digital 5.1 channel processor or amplifier. This Unit automatically recognizes DVDs that have been recorded with Dolby Digital.



Some sources marked Dolby Digital may be recorded in Dolby Surround, a 2 channel system. Look for this logo on your DVD Unit.

Dolby Pro Logic II creates five full-bandwidth output channels from two-channel sources. This is done using an advanced, high-purity matrix surround decoder that extracts the spatial properties of the original $recording\ without\ adding\ any\ new\ sounds\ or\ tonal\ colorations.$



DOLBY

Movie Mode (MOVIE)


The Movie mode in Pro Logic II is very similar to that of the original Pro Logic decoder. The main difference is that it has stereo surround channels and no surround filter, unlike Pro Logic which has a mono surround channel and a 7 kHz surround filter. Movie mode is the standard required for all A/V systems. When an autosound unit has a video screen, it is also considered an A/V system. It can be called simply "Pro Logic II".

Music Mode (MUSIC)

The Music mode offers users some flexibility to control the end results to their own taste. Music mode should not be used with THX audio processing mode. Music mode is recommended as the standard mode for autosound music systems (without video). and is optional for A/V systems. It is recommended that Music mode be identified as the "Music" version of Pro Logic II, to distinguish it from the Movie mode.









Adjusting the Sound

Pro Logic Emulation Mode (PL II and EMU)

The Pro Logic emulation mode offers users the same robust surround processing as original Pro Logic, in case the source content is not of optimum quality, or if there is a desire to hear the program more "as it used to be". When this mode is used, it is called Pro Logic, as before. There is no "Pro Logic I" mode. The Pro Logic emulation mode is optional. Dolby does not require PLII products to use the original Pro Logic decoding algorithm. However, if the DSP contains the original Pro Logic code, and if the product maker would like to use it, this is quite acceptable and even encouraged. A product must not offer both original Pro Logic and the Pro Logic emulation mode

Matrix Mode (MATRX)

The Matrix mode is the same as the Music mode except that the directional enhancement logic is turned off. It may be used to enhance mono signals by making them seem "larger". The Matrix mode may also find use in auto systems, where the fluctuations from poor FM stereo reception can otherwise cause disturbing surround signals from a logic decoder. The ultimate "cure" for poor FM stereo reception may be simply to force the audio to mono.

Manufactured under license from Dolby Laboratories.

'Dolby', 'Pro Logic' and the double-D symbol are trademarks of Dolby Laboratories.

"DTS" and "DTS Digital Out" are trademarks of Digital Theater Systems, Inc.

To select the listening channel

- 1. When the disc is stopped, you can press the 5.1/2.1 CH button on the remote control to select different speakers output status shown on below table.
- 2. At AV IN function mode, you also can press the 🔀 PRO LOGIC II button repeatedly on the remote control to select PRO LOGIC II (indicator on the front panel of display will illuminate).
- 3. You can active or off subwoofer output by setup menu.

- · The wording "2.1 CH" will be corresponded to the audio/sound output from Front Left and Front Right speakers plus the Subwoofer.
- 5.1/2.1 CH button is no response to JPG CD-ROM or JPG/MP3 CD-ROM. Please select 5.1/2.1 CH output before putting such CD-ROM.
- Dolby Digital 5.1 CH will not be activated on Pro Logic II.

The following table shows which speakers are working in the various modes.

FUNCTION	DISCS	5.1 / 2.1 CH Button	L/R SPEAKER (SMALL/ LARGE)	SUB- WOOFER ON/OFF	Dolby Pro Logic II Selection						
					EMU	MATRIX	MUSIC	MOVIE	BY PASS		
		Ì	SMALL	ON	5.1	5.1	5.1	5.1	5.1or 2.1		
		5.1CH	LARGE	ON	5.1	5.1	5.1	5.1	5.1or2		
	DVD/			OFF	5	5	5	5	5 or 2		
CD	CD		SMALL	ON	2.1	2.1	2.1	2.1	2.1		
		2.1CH	LARGE	ON	2	2	2	2	2		
DVD MODE MP 3	L	L		OFF	2	2	2	2	2		
	MP3	5.1CH			5.1	5.1	5.1	5.1	5.1		
		2.1CH		ON	2.1	2.1	2.1	2.1	2.1]	
					OFF	2	2	2	2	2	Dolby Pro
		5.1CH		ON	5.1	5.1	5.1	5.1	5.1	Logic II not	
	I DOM			OFF	5	5	5	5	5	applied on Tuner, MP3	
PCM DVD			SMALL	ON	2.1	2.1	2.1	2.1	2.1	and PCM	
		2.1CH	LARGE	ON	2	2	2	2	2	DVD.	
				OFF	2	2	2	2	2]	
TUNER					2.1	2.1	2.1	2.1	2.1	L	
			SMALL	ON	5.1	5.1	5.1	5.1	5.1		
AV_IN			LARGE	ON	5.1	5.1	5.1	5.1	2.1]	
					OFF	5	5	5	5	5	Ì

- 5.1- Represents FRONT LEFT/RIGHT, REAR LEFT/RIGHT, CENTER speakers and SUBWOOFER
- 2.1 Represents FRONT LEFT/RIGHT speakers and SUBWOOFER
- 5 Represents FRONT LEFT/RIGHT, REAR LEFT/RIGHT and CENTER speakers
- 2 Represents FRONT LEFT/RIGHT speakers







Playing a Disc

This owner's manual explains the basic instructions of this DVD Unit. Some DVD discs are produced in a manner that allows specific or limited operation during playback. As such, the DVD Unit may not respond to all operating commands. This is not a defect in the DVD Unit. Refer to the instruction notes of discs.

" way appear on the TV screen during operation. A " " means that the desired operation is not permitted by the DVD Unit or the disc.

Turning on the unit

Press the I / ϕ power button on the front panel, the STANDBY indicator will light up. Then select the desired function by pressing the **FUNCTION** button. **Note:** Remote control can turn on the unit only if the unit is in standby mode.

WARNING

BEFORE TRANSPORTING THE UNIT, TAKE OUT ALL DISCS FROM DISC TRAY.

To turn off the unit

Press the I / \circlearrowleft power button on the front panel, the unit will be turned off and the display will go dark. If you press **STANDBY/ON** \circlearrowleft button on the remote control to turn off the unit, it will bring the unit to standby mode.

Playing a Disc

- While the unit is in standby mode, press FUNCTION button to select DVD mode. It will take a while for disc holder automatically rotating to load disc 1.
- 2. If the display shows "Load" or "NO DISC", press the ≜ OPEN / CLOSE button. The disc tray opens.
- 3. Press DISC 1 5 select button on the remote control, after a while, the disc tray will automatically close and then open. Disc holder will automatically rotate one cycle and stop.
- 4. Place the first disc on the disc holder with the label side up.
- 5. Press DISC 1 5 select button on the remote control or DISC SKIP button on the front panel to rotate disc holder to load other discs.
- 6. Press the ▲ OPEN / CLOSE button. The disc tray closes.
 - It takes a short while for your unit to load the discs. After loading, for some discs, the unit will automatically start playback of the disc.
- 7. Press the ► PLAY button.
- 8. Press DISC 1 5 select buttons or DISC SKIP button on the front panel to select other disc playback.

Notes:

- Use the A OPEN / CLOSE button on the front panel to open or close the disc tray. Do not push the disc tray or you may damage the Unit.
- Let the disc tray open completely before removing the discs. Press the ≜ OPEN / CLOSE button to close the disc tray after you remove the discs.
- If you use the ≜ OPEN / CLOSE button on the front panel to open the disc tray, the unit will stop playing. The disc holder will rotate half circle so that the disc can be taken out. If you use the ≜ OPEN / CLOSE button on the remote control to open the disc tray , the playback will not be affected.

Pausing playback (still mode)

Press the II PAUSE button. To resume normal playback, press the ▶ PLAY button.

Stopping playback

Press the **STOP** button at the location where you want to interrupt playback. To resume playback at the position where the disc was stopped, press the **PLAY** button.

If you press the **STOP** button twice, the Unit's memory will be cleared and pressing the **PLAY** button will reset the disc to the beginning.

To skip to a different track

- Press the I◀◀ SKIP button once to skip to the start of the previous track.
- Press the ▶▶ SKIP button to skip to the next track.
- For audio CD disc, use the number buttons (remote control only) to jump straight to that track number.

Notes:


- During playback, disc tray can be opened/closed to add disc and the current disc playback will not be interrupted (only by pressing

 OPEN / CLOSE button on the remote control).

E - 19







Fast Forward/Fast Reverse OVD CCD



- 1. Press the **TUNING** → or **TUNING** button when a disc is playing.
- The disc begins fast scan at x2 speed.
- Four speeds are available. Each time **TUNING** → or **◄TUNING** button is pressed, the speed of fast scan changes in the following sequence: $\Rightarrow x2 \longrightarrow \Rightarrow x4 \longrightarrow \Rightarrow x8 \longrightarrow \Rightarrow x20$



Note: You also can press I◄◄ SKIP/TUNING ►►I button on front panel repeatedly to select different fast scan speed.

2. Press the PLAY button when you reach the desired point to resume playback at normal speed.

Slow-motion play ODVD

- 1. Press the **SLOW** I▶ or **◄I SLOW** button in the play mode.
 - Two speeds are available. Each time SLOW I► or < | SLOW button is pressed, the speed of slow-motion playback changes in the following sequence: • 1.2 - 1.14 ■ 1/2 → ■ 1/4
- 2. Press the PLAY button to return to the normal playback speed.




While you are playing a disc, press the ▶► NEXT button of the remote or ▶► SKIP/TUNING button of front panel to move to the beginning of the next chapter or track. Press the I◄◄ PREV button of the remote or I◄◄ SKIP/TUNING button of the front panel to move to the previous chapter or track and automatically start playing it.

Zooming into an image

While a disc is playing, press the **ZOOM/NTSC/PAL** button.

- While an image is zoomed, you can use \blacktriangle , \blacktriangledown , \blacktriangleleft and \blacktriangleright button to shift the view and display the part you want.
- To return to the normal view, press the ZOOM/NTSC/PAL button until the "Qoff" symbol shows. The screen will return to normal.



• When you reach the edge of the image, the display will not shift anymore in that direction.




Playing a Disc

Angle selection

Some DVDs contain scenes which have been shot from a number of different angles. For these discs, the same scene can be viewed from each of these different angles.

 While you are playing a DVD with different angles recorded, press the ANGLE button to view the number of the current angle.



- 2. Press the ANGLE button repeatedly to change the scene to the next angle in those recorded.
 - · About two seconds later, playback continues from the new angle you selected.
 - If no button is pressed within 10 seconds, playback continues without changing the current angle.

Sequence of angle shots

(Example)



Notes:


- This function can only be used for discs on which scenes shot from multiple angles have been recorded.
- If only one angle is recorded, " " is displayed.



Audio selection

On some discs, the sound is recorded in two or more formats. Follow the directions below to select the type of playback.

1. While a disc is playing, press the AUDIO button to show the current audio format number.



2. Press the AUDIO button repeatedly to select the desired audio format.

Notes

- If only one audio format is recorded, the number does not change.
- About two seconds later, playback continues in the new audio format.







Playing a Disc

Subtitle selection

1. While a DVD is playing, press the **SUBTITLE** button to display the current language setting, as shown in the example below.



2. Press the SUBTITLE button repeatedly to select the desired subtitle language.

Notes:

- If only one language is recorded, the language does not change.
- About two seconds later, playback continues with the new subtitle you selected.
- The number of languages recorded differs depending on the disc.
- If no button is pressed within a few seconds, playback continues without changing the current subtitle.
- This function can only be used for discs on which subtitles have been recorded in multiple languages.
- On some DVDs, subtitles are activated from the main menu of the DVD. Press the MENU button to activate the
 main menu.







Special Functions


DISPLAY function

Using DISPLAY, you can check and change the current settings of the following items: ANGLE, AUDIO and SUBTITLE.

· While the disc is playing, press the DISPLAY button to display the screen shown below.

Elapsed time: Elapsed time from the beginning of the chapter which is currently playing.

Remaining time: Remaining time of the title which is currently playing.



- Press the DISPLAY button twice to display the screen shown as below.
- Press the ANGLE, AUDIO and SUBTITLE button to change the selected item.



Title skip

- The number of the title currently playing and total titles of disc.
- Press the GOTO button to set your desired title, then press the ENTER button to confirm.

Chapter skip

- The number of the chapter currently playing and total chapters of the currently played title.
- Press the **GOTO** button to set your desired chapter, then press the **ENTER** button to confirm.

Time skip

- Elapsed time from the beginning of the currently playing chapter and the remaining time from the beginning of the currently playing title.
- Press the GOTO button to set your desired point to start playback, then press the ENTER button to confirm.

Angle setting

- The current angle is displayed. When a disc with only one angle is played back, "Angle 1/1" is displayed.
- Press the **ANGLE** button to select the desired angle.

Audio setting

- The type of audio currently selected is displayed.
- Press the **AUDIO** button to select your desired type of audio.

Subtitle setting

- The subtitle number and language currently selected is displayed. When a disc with only one subtitle is played back, "=1/1 Eng" is displayed.
- Press the SUBTITLE button to select your desired language.

GOTO function

This function allows you to skip directly to any part of the disc while a disc is playing.



Note:

• After settings, press the DISPLAY button again to return to the normal screen.

E - 23







Special Functions

Locating a specific title



If a DVD disc contains title numbers, you can locate a specific title by directly selecting a title number.

- 1. In stop mode, press the GOTO button.
- 2. Press ▼, ◀ or ▶ button to highlight a specific field and press the corresponding number button(s) for the title you want.
- 3. Press the ENTER button to confirm. The Unit will start playback about 3 seconds later.



• Pressing the **CLEAR** button resets the title number.





Locating a specific title / chapter / track CDVD CCD

 $If you know the \ title \ / \ chapter \ / \ track \ number \ you \ want \ to \ play, \ you \ can \ locate \ a \ specif \ title \ / \ chapter \ / \ track \ by \ directly$ selecting a title / chapter / track number.

- 1. Press the GOTO button to search your desired title / chapter / track.
- 2. Press ▼, ◀ or ▶ button to highlight a title / chapter / track and press the corresponding number button(s) for the chapter you want.
- 3. Press the ENTER button to confirm. The Unit will start playback about 3 seconds later.



• Pressing the **CLEAR** button resets the title / chapter / track number.







Special Functions

Locating a specific time OVD CCD



You can move to a specific location by entering its corresponding time (hours, minutes, seconds)

- 1. Press the GOTO button.
- 2. Press ▲ or ▼ button to highlight time.






- 3. Press the corresponding number buttons for the setting point you want.
- The first two numbers you entered represent hours.
- The second two numbers you entered represent minutes.
- The third two numbers you entered represent seconds.
- 4. Press the ENTER button to confirm. The Unit will start playback about 3 seconds later.

- · Some discs may not respond to this process.
- Some scenes may not be located as precisely as you specified.
- This method for accessing specific locations is available only within the current title of the DVD disc.
- You can move through the menu by pressing the ▲ and ▼ buttons.
- · Pressing the CLEAR button resets the time.







- 2. Press the ANGLE button repeatedly to select your desired angle.
- 3. The Unit will change to your desired angle about 3 seconds later.


Audio setting ODVD

- 1. Press the **DISPLAY** button twice. The FUNCTION menu is \$\int_{1/3\text{ Fre}} \text{ DI Dis Ch} \rightarrow \int_{2/3\text{ Spe}} \text{ DI Dis Ch} \rightarrow \int_{3/3\text{ Dis Ch}} \rightarrow \int_{3/3\text{ Spe}} \text{ DI Dis Ch} \rightarrow \int_{3/3\text{ Dis Ch}} \rightarrow \int_{3/3\text{ Di displayed on the screen and you can see how many audio formats are recorded on the disc.
- 2. Press the AUDIO button repeatedly to select your desired type of audio.
- 3. The Unit will change to your desired type audio about 3 seconds



- 1. Press the DISPLAY button twice. The FUNCTION menu is displayed on the screen and you can see how many subtitle formats are recorded on the disc.
- 2. Press the SUBTITLE button repeatedly to select your desired language.
- 3. The Unit will change to your desired language about 3 seconds

25









CD / DVD programmable memory

Programmable memory ODVD

The two types of programmed playback provided by this Unit are title programmed playback and chapter programmed playback.

Title / Chapter programmed playback

- 1. Press the **MEMORY** button while the disc is stopped.
- 2. Enter the title numbers in ■. Use ◀ or ▶ button to move the highlight to chapter and enter the chapter numbers



- 3. Use ◀, ▶, ▲ or ▼ button to move to the other field.
- 4. Repeat steps 2 to 3.
- 5. Press the ▶ PLAY button to start the programmed playback.

- If you press the \blacksquare STOP button, the programmed selections will be cleared.
- If you press the CLEAR button while you are entering a title or chapter, the currently entered numbers will be erased and you can reset the numbers again.

Programmable memory CD Track programmed playback

- 1. Press the **MEMORY** button while the disc is stopped.
- 2. Enter the track numbers in



- 3. Use ◀, ▶, ▲ or ▼ button to other field.
- 4. Repeat steps 2 to 3.
- 5. Press the **PLAY** button to start the programmed playback.

Note:


- If you press the CLEAR button while you are entering a track, the currently entered numbers are erased and you can reset the numbers again.
- When the unit is playing at program memory mode, the "MEMORY" will display on LCD display window.



Repeat Playback

You can play a specific title or chapter repeatedly.

(Title repeat, chapter repeat, A-B repeat)



You can play the same title repeatedly.

1. While the disc is playing, press the **REPEAT DISC** button until the "RepeatTitle" indicator displays on the screen. The current title is played repeatedly.



Repeating a chapter

You can play the same chapter repeatedly.

 While the disc is playing, press the REPEAT DISC button until the "Repeat Chapter" indicator displays on the screen. The current chapter is played repeatedly.



To resume normal playback

3. While the disc is playing, press the **REPEAT DISC** button until the "Off" indicator displays on the screen.





You can play a single track and whole disc repeatedly.

Repeating a single track CCD

You can play the same track repeatedly.

 While the disc is playing, press the REPEAT DISC button until the "Repeat Single" indicator displays on the screen. The current track is played repeatedly.



Repeating a whole disc

 While the disc is playing, press the REPEAT DISC button until the "Repeat All" indicator displays on the screen. The whole disc is played repeatedly.



To resume normal playback

 Press the REPEAT DISC button until the "off" indicator displays on the screen.

27









Repeat Playback

Repeating a specific section (



You can play a specific section repeatedly.

 While the disc is playing, press the REPEAT A-B button at the beginning of the section (Rep A-) is displayed you want to play repeatedly.



2. Press the **REPEAT A-B** button again at the end of the section (Rep A - B) is displayed.



3. The Unit will immediately begin replaying your selection.

To resume normal playback

4. While the disc is playing, press the **REPEAT A-B** button until the "off" indicator displays on the screen.




Notes:

- A-B repeat can only be used within the same title. If the start and end of the section to be repeated are in different titles, A-B repeat is cancelled.
- The A-B repeat function does not operate in scenes where different camera angles are recorded.







This Unit will play MP3 and Picture files recorded on CD-R discs.

Playing a MP3 file disc

- 1. Press the **OPEN /CLOSE** button, the disc tray opens.
- 2. Insert a MP3 file disc on the disc tray with the label side up.
- 3. Press the ♠OPEN/CLOSE button, the disc tray closes.
- The Unit will take a short while to load the disc and automatically begin playback.



To pause playback

Press the ■PAUSE button. To resume playback again, press the ►PLAY button.

To stop playback

• Press the ■STOP button.

To skip to the next or previous file

- Press the PINEXT button on the remote control briefly while playing, to skip ahead to the beginning of the
 next file. Each time you press the button consecutively, the beginning of the next file is located and played
 back.
- Press the I◄¬PREV (Previous) button on the remote control briefly while playing, to skip back to the beginning of the previous file. Each time you press the button consecutively,the beginning of the previous files is located and played back.
- You also can press the GOTO button, set the track number you want and then press the ENTER button.

Note:

· You can not play in Fast reverse or Fast forward during MP3 playback.

On-screen display

Turn on your TV to view the on-screen display of MP3 files.

Press the ▲, ▼, ◄ or ▶ CURSOR button on the remote control to select the file you want to listen to, then
press ENTER button and this selected file is located and played back.

Notes:

The ability of this Unit to read MP3 discs is dependent on the following:

- The Bit Rate must be within 64 256 kbps.
- The total number of files on the disc should not exceed 254.
- · The maximum number of directories should not exceed 32.
- The maximum depth level of directories should not exceed 4.
- File names should be named using 12 or fewer letters and/or numbers, and must incorporate the "MP3" file extension. EXAMPLE: ******** MP3 where each * is a letter or number.
- Use only letters and / or numbers in file names. If you use special characters, the file and/or folder names
 may not be displayed correctly on the on-screen display.
- When recording on CD-R discs, use 74-minute (650MB) discs.
- The CD-R or CD-RW discs should be "finalized" in computer by "single session format".
- See your CD/MP3 creation software for details.










Playing a Picture file disc

- 1. Press the **OPEN /CLOSE** button, the disc tray opens.
- 2. Insert a Picture CD on the disc tray with the label side up.
- 3. Press the **OPEN/CLOSE** button, the disc tray closes.
- 4. Select the disc by pressing **DISC 1 5** button.
- 5. The unit will take a short while to load the disc.
- 6. Press the ►PLAY button. The next picture will automatically display after 6 seconds.

Full-Screen Review





Thumbnail Review

Notes:

- If you press the MENU button on the remote control in full-screen review, the Unit will display a menu of 9 thumbnail images.
- Use th cursor to highlight the PREV I or NEXT I in thumbnail screen and then press ENTER to review other images. If you want to review one image in full-screen, you can use the CURSOR ♠, ▶, ♠ or ▼ buttons to highlight the image and then press the ENTER button to confirm. The image you selected will show on TV in Full-Screen and automatically display one by one again in about 6 seconds intervals.
- You can press the PAUSE button to interrupt playback, and press the ►PLAY button to resume playback.
- You also can use GOTO function or use the numbered buttons to enter the number to quickly select any
 image.
- You can press the **ZOOM** button to enlarge the picture in 3 levels.
- Press the ANGLE button on the remote control to rotate the picture orientation by 90°.

Playing a MP3/Picture file disc

- 1. Press the **OPEN /CLOSE** button, the disc tray opens.
- 2. Insert a MP3 files/Picture CD on the disc tray with the label side up.
- 3. Press the **≜OPEN/CLOSE** button, the disc tray closes.
- 4. Select the disc by pressing $\boldsymbol{\text{DISC 1 5}}$ button.
- 5. The unit will take a short while to load the disc.
- Use ◀ or ▶ button to select MP3 or Picture CD, then press the ENTER button.



Note:

• The **SETUP** button does not work during MP3 or Picture Disc playback or stop.







Tuning into a station manually

- 1. Press **FUNCTION** button on the remote until the frequency band appears on the display.
- Press the BAND button on the remote or STOP/BAND button on the front panel to select the desired band.
- 3. Press the ◀ TUNING ➤ button on the remote or i◀ SKIP/TUNING ➤ on the front panel to tune in the desired station.



FM Stereo

• Press the **FM MODE** button on the remote until " 5 TERE " appears on the display.

Weak FM stations

• Press the **FM MODE** button on the remote until the "Malla" word appears on the display. Background noise will be reduced but the signal reproduced will be mono. To restore stereo reception, press the **FM MODE** button on the remote to select STEREO.

Note:

• The left / right front speakers and subwoofer are activated only.

To search for a station automatically

- Hold down the ◀ TUNING ➤ buttons on the remote or I◀ SKIP/TUNING ➤ buttons on the front panel for 1 to 2 seconds, and a station is searched for automatically. After tuning in a station, the search stops.
- The search may not stop at a station with a very weak signal.



Presetting stations

You can tune into a stored station directly by entering the preset number.

- 20 stations on FM band can be preset.
- 20 stations on AM band can be preset.
- 1. Press FUNCTION button until the frequency band appears on the display.
- 2. Press the **BAND** button to select the desired band.
- 3. Use the **◄ TUNING >>** button to find your desired station.
- 4. Press the **MEMORY** button on the remote.
- 5. Press the ▶►I NEXT or PREV I◄◄ button to select the preset number and press the MEMORY button on the remote to store the station.
- 6. Repeat steps 2-5 to store other stations.

Tuning into a preset station

- 1. Press FUNCTION button until the frequency band appears on the display.
- 2. Press the BAND button to select the desired band.
- Press the ► PLAY button and ►►I NEXT or PREV I ◄ button on the remote, or press the ► PLAY/PRESET button on
 the front panel to select the presetted station or use the numbered buttons to enter the number to select the presetted
 station

Example: To select preset number 15, press the +10 and 5 buttons.


To select preset number 10, press the +10 and 0 buttons.





LANGUAGE setting

- 1. Press FUNCTION button until DVD appears on the display.
- 2. Press the **STOP** button so that no disc is playing.
- 3. Press the **SETUP** button.
- 4. Use ◀ or ▶ button to select the Language, then press the **ENTER** button.
- 5. Use ▲ or ▼ button to English, then press the **ENTER** button. The screen will change to English Wordings immediately.
- 6. To exit the FUNCTION SETUP MENU and return to the normal screen, press the **RETURN** button.










VIDEO setting

TV Shape

- 1. Press the **SETUP** button.
- 2. Use ◀ or ▶ button to select Video, then press the ENTER button.
- 3. Use ▲ or ▼ button to select TV Shape, then press the **ENTER** button.
- 4. Use ▲ or ▼ button to shift and select the TV type, then press the **ENTER** button.
- 5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the **RETURN** button.



Cut off when a wide-screen video image is played.





- When wide-screen video material is played, this mode clips the right and left sides of the image so that it can be viewed on a conventional TV screen.
 - Some wide-screen DVDs that do not permit Pan Scan mode playback are automatically played in letterbox mode (black bands top and bottom).



4:3 Letter Box

 When wide-screen video material is played in this mode on a conventional TV screen, black bands appear at the top and bottom of the screen.



16:9 Wide-screen

- This is the correct mode for playing wide-screen videos on a widescreen TV.
- You must also set the screen mode on your wide-screen TV to "FULL".


The actual appearance of the image depends on the screen mode setting of your wide-screen TV.

Notes:

- The displayable picture size is preset on the DVD disc. Therefore the playback picture of some DVD discs may not
 conform to the picture size you select.
- When you play DVD discs recorded in the 4:3 picture size only, the playback picture always appears in the 4:3 picture size regardless of the TV shape setting.
- If you select 16:9 wide-screen mode and you own a 4:3 TV set, the DVD playback picture will be horizontally distorted during playback. Images will appear to be horizontally compressed. Always be sure that your TV shape conforms to the actual TV in use.

(continued on n

L - 3.










Video Output

- 1. Press the **SETUP** button.
- 2. Use ◀ or ▶ button to select Video, then press the **ENTER** button.
- 3. Use \blacktriangle or \blacktriangledown button to select Video Output, then press the **ENTER** button.
- 4. Use ▲ or ▼ button to shift and select the signal, then press the **ENTER** button.
- 5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the RETURN button.



CVBS: Corresponding to your TV which has a Video or S-Video input.

YUV: Corresponding to your TV which has a YUV input.

Attention:

Always set Video Output in CVBS, otherwise, the picture on the TV may be distorted. If this occurs, and you cannot see the screen, press the **P. SCAN** button twice until the "CVBS" display.





Brightness

- 1. Press the SETUP button.
- **2.** Use \blacktriangleleft or \blacktriangleright button to select Video, then press the **ENTER** button.
- 3. Use ▲ or ▼ button to select Brightness, and then press the **ENTER** button.
- 4. Use ▲ or ▼ button to shift and select the Off/On, then press the **ENTER** button.
- 5. If you want to exit the SETUP MENU and return to the normal screen, press the RETURN button.



On: Picture will be brighter to clarify details.

Off: Picture will have deepened colors.

Note

• Actual effect on pictures will vary depending on the TV.





Edges

- 1. Press the **SETUP** button.
- 2.Use ◀ or ▶ button to select Video, then press the ENTER button.
- **3.**Use ▲ or ▼ button to select Edges, and then press the **ENTER** button.
- **4.** Use ▲ or ▼ button to shift and select the Sharpen / Soften / Off, then press the **ENTER** button.
- 5. If you want to exit the SETUP MENU and return to the normal screen, press the **RETURN** button.



Sharpen: Fine detail will be easier to see.

Soften: Soft-focus effect.

Off: Picture will be returned to normal.








AUDIO setting

Digital Out

- 1. Press the **SETUP** button.
- 2. Use the cursor ◀ or ▶ button to select Audio, press the ENTER button.
- Use the cursor ▲ or ▼ button to select Digital Out, and then press the ENTER button repeatedly to select Digital Out type.
- 4. To exit the FUNCTION SETUP MENU and return to the normal screen, press the RETURN button.



Raw: Does not have a Dolby Digital Decode.


PCM : Dolby Digital decoding to PCM digital format.





L/R Speaker

- 1. Press the **SETUP** button.
- 2.Use the cursor \blacktriangleleft or \blacktriangleright button to select the Audio, press the ENTER button.
- 3.Use the cursor \blacktriangle or \blacktriangledown button to L/R Speaker, and then press the ENTER button.
- 4. Use the cursor \blacktriangle or \blacktriangledown button to select the desired setting, and then press the **ENTER** button.
- 5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the RETURN button.



L/R Speaker

Small: Small size of Speaker.

Large: Large size of Speaker. (speaker diameter normally larger than 4 inch or 10 cm)

Note

• You can adjust the channel balance on your Unit. Please see "ADJUSTING THE SOUND" on page 17.


E - 36





Subwoofer

- 1. Press the **SETUP** button.
- 2. Use the cursor ◀ or ▶ button to select the Audio, press the ENTER button.
- 3. Use the cursor ▲ or ▼ button to Subwoofer, and then press the ENTER button.
- 4. Use the cursor ▲ or ▼ button to select the desired setting, and then press the **ENTER** button.
- 5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the **RETURN** button.



Subwoofer

"On" should be selected if your subwoofer is connected.

If "Off" is selected, no sound will be emitted by subwoofer.

Note:


• You can adjust the channel balance on your Unit. Please see "ADJUSTING THE SOUND" on page 17.





Surround Delay

- 1. Press the **SETUP** button.
- 2. Use the cursor ◀ or ▶ button to select the Audio, press the ENTER button.
- 3. Use the cursor ▲ or ▼ button to Surround Delay, then repeatedly press the **ENTER** button to select the desired Surround Delay type. 0/15ms, 5/20ms, 10/25ms or 15/30ms appears.
- 4. To exit the FUNCTION SETUP MENU and return to the normal screen, press the RETURN button.



Notes

- The first number represents the Dolby Digital and the second number represents the Pro Logic.
- The delay adjustment depends on the location of your surround speakers and the front speakers. If the location
 of the surround speakers are closer than the front speakers, the delay adjustment can compensate the distance
 difference.


E - 37





Center Delay


- 1. Press the **SETUP** button.
- 2. Use the cursor ◀ or ▶ button to select the Audio, press the ENTER button.
- 3. Use the cursor ▲ or ▼ button to Center delay, then repeatedly press the **ENTER** button to select the desired Center Delay type. 0ms, 1ms, 2ms, 3ms, 4ms or 5ms appears.
- 4. To exit the FUNCTION SETUP MENU and return to the normal screen, press the **RETURN** button.





Note:

This delay adjustment depends on the location of your center speaker. If the distance between the center speaker
and the listener is less than the distance between the front right and left speaker and the listener, this delay
adjustment is balanced.

Pink noise







4. Use the cursor ▲ or ▼ button to select the desired setting, and then press the **ENTER** button.

5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the **RETURN** button.



Pink noise

Off: Pink noise test mode should always be switched off, unless you are testing your speakers.

Left: Pink noise comes out from front left speaker for testing. **Center**: Pink noise comes out from center speaker for testing. **Right**: Pink noise comes out from front right speaker for testing.

Left sur: Pink noise comes out from rear surround left speaker for testing. **Right sur:** Pink noise comes out from rear surround right speaker for testing.

38

Subwoofer: Pink noise comes out from subwoofer for testing.

Note:

 When using the pink noise generator to test your speakers, you can press the SOUND button on the remote control to adjust the channel balance. Please see "Adjusting the Sound" on page 17.







RATING setting

Password/Parental lock

DVD discs equipped with the password function are rated according to their content. The contents allowed by a parental lock level and the way a DVD disc can be controlled may vary from disc to disc.

For example, if the disc allowed, you could edit out violent scenes unsuitable for children and replace them with more suitable scenes, or you could lock out playback of the disc altogether.

- 1. Press the **SETUP** button.
- 2. Use ◀ or ▶ button to select Rating, press the ENTER button.
- 3. Use ▲ or ▼ button to select parental lock and then press the ENTER button repeatedly to set the parental lock level.
- 4. Use ▲ or ▼ button to shift and select Password, enter your 4-digit security code and then press the **ENTER** button.

If you make a mistake before pressing the ENTER button, press the CLEAR button and enter your 4-digit security code again.

You cannot play DVD discs rated higher than the level you selected unless you cancel the parental lock function.

The parental lock level is equivalent to the following ratings.

 Level 1 : Kid Safe
 Level 5 : PG_R

 Level 2 : G
 Level 6 : R


 Level 3 : PG
 Level 7 : NC_17

 Level 4 : PG_13
 Level 8 : Adult

5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the **RETURN** button.

Indicates Parental lock is NOT active.

The Parental lock is active.



If you forget the password, you can erase your current password by pressing number button 8 on the remote four times, then press the ENTER button to confirm the setting.

PASSWORD:8888

E - 39






Factory Set

If you want to return the initial language setting to the factory default, do the following:

- 1. Press the **SETUP** button.
- 2.Use \blacktriangleleft or \blacktriangleright button to select the Rating, then press the **ENTER** button.
- 3. Use ▲ or ▼ button to shift and select the Factory Set, then press the **ENTER** button.
- 4. Use ▲ or ▼ button to shift and select Yes, then press the **ENTER** button.
- 5. To exit the FUNCTION SETUP MENU and return to the normal screen, press the RETURN button.



Note:

When you reset the Unit to the factory default, the Unit will take 3-5 seconds to reset.





Language Code List for Disc Language

Code	Language Name	Code	Language Name	Code	Language Name	Code	Language Name
AA	Afar	FY	Frisian	MG	Malagasy	SL	Slovenian
AB	Abkhazian	GA	Irish	MI	Maori	SM	Samoan
AF	Afrikaans	GB	Scots Gaelic	MK	Macedonian	SN	Shona
AM	Ameharic	GL	Galician	ML	Malayalam	SO	Somali
AR	Arabic	GN	Guarani	MN	Mongolian	SQ	Albanian
AS	Assamese	GU	Gujarati	MO	Moldavian	SR	Serbian
AY	Aymara	НА	Hausa	MR	Marathi	SS	Siswat
AZ	Azerbaijani	HI	Hindi	MS	Malay	ST	Sesotho
BA	Bashkir	HR	Croatian	MT	Maltese	SU	Sundanese
BE	Byerlorussian	HU	Hungarian	MY	Burmese	SV	Swedish
BG	Bulgarian	HY	Armenian	NA	Nauru	SW	Swahili
ВН	Bihari	IA	Interlingua	NE	Nepali	TA	Tamil
BI	Bislama	ΙE	Interlingue	NL	Dutch	TE	Telugu
BN	Bengali	IK	Inupiak	NO	Norwegian	TG	Tajik
	Bangla	IN	Indonesian	OC	Occitan	TH	Thai
ВО	Tibetan	IS	Icelandic	OM	(Afan) Oromo	TI	Tigrinya
BR	Breton	IT	Italian	OR	Oriya	TK	Turkmen
CA	Catalan	IW	Hebrew	PA	Panjabi	TL	Tagalog
СО	Corsican	JA	Japanese	PL	Polish	TN	Setswana
CS	Czech	JI	Yiddish	PS	Pashto, Pushto	TO	Tonga
CY	Welsh	JW	Javanese	PT	Portuguese	TR	Turish
DA	Danish	KA	Georgian	QU	Quechua	TS	Tsonga
DE	German	KK	Kazakh	RM	Rhaeto-	TT	Tatar
DZ	Bhutani	KL	Greenlandic		Romance	TW	Twi
EL	Greek	KM	Cambodian	RN	Kirundi	UK	Ukrainian
EN	English	KN	Kannada	RO	Romanian	UR	Urdu
EO	Esperanto	KO	Korean	RU	Russian	UZ	Uzbek
ES	Spanish	KS	Kashmiri	RW	Kinyarwanda	VI	Vietnamese
ET	Estonian	KU	Kurdish	SA	Sanskrit	VO	Volapük
EU	Basque	KY	Kirghiz	SD	Sindhi	WO	Wolof
FA	Persian	LA	Latin	SG	Sangho	XH	Xhosa
FI	Finnish	LN	Lingala	SH	Serbo-	YO	Yoruba
FJ	Fiji	LO	Laothian		Croatian	ZH	Chinese
FO	Faroese	LT	Lithuanian	SI	Singhalese	ZU	Zulu
FR	French	LV	Latvian, Lettish	SK	Slovak		







Cleaning Disc

A defective or soiled disc inserted into the Unit can cause sound to drop out during playback.

Handle the disc by holding its inner and outer edges.

- Do NOT touch the surface of the unlabeled side of the disc.
- Do NOT stick paper or tape on the surface.
- Do NOT expose the disc to direct sunlight or excessive heat.
- Clean the disc before playback. Wipe the disc from the center outward with a cleaning cloth.
- NEVER use solvents such as benzine or alcohol to clean the disc.
- Do NOT use irregular shape discs (example : heart shaped, octagonal, etc.). They may cause malfunctions.

Cleaning the Unit

- Be sure to turn the Unit off and disconnect the AC power cord before maintaining the Unit.
- Wipe the Unit with a dry soft cloth.

If the surfaces are extremely dirty, wipe clean with a cloth which has been dipped in a weak soap-and-water solution and wrung out thoroughly, then wipe with a dry cloth.

· Never use alcohol, benzine, thinner, cleaning fluid or other chemicals. Do NOT use compressed air to remove dust.

Important Note

Before transporting the Unit, remove disc from the disc tray.





Trouble Shooting Guide

SYMPTOM CAUSE (AND REMEDY)

No power.

• Check that the AC power cord is connected.

No picture.

• The region number of the disc doesn't match the region number of this Unit.



- The TV is not set to receive DVD signal output.
- The video cable is not connected.
- The TV is not turned on.

The picture is not clear.

- Clean the disc.
- If video from your system has to go through your VCR to get to your TV, the copy-protection
 applied to some DVD programs could affect picture quality. If you still experience problems
 after checking your connections, please try connecting your Unit directly to your TV.
- The disc is scratched.
- The DVD unit may be set to progressive scan, moreover, TV does not support Progressive Scan component video signal. Press the P. SCAN button twice until the "CVBS" display.

E - 4



SYMPTOM

CAUSE (AND REMEDY)

- The location and orientation of the antenna are incorrect. If you use an indoor antenna, change to an outdoor antenna.
- The TV antenna wire is too close to the Unit. Separate the antenna wire of the TV set from the Unit.

No sound or only a very low-level sound is heard.

- Check that the speakers and equipment are connected securely.
- Make sure that you've selected the correct equipment on the system.
- The system is in pause mode or in Slow-motion Play mode. Press the ➤ PLAY button to return to normal play mode.
- Fast forward or fast reverse is performed. Press the PLAY button to return to normal play mode.
- · Check the speaker settings.
- Make sure that AUDIO output and AV IN input connections are correct.
- · Adjust the speakers volume.
- The DTS DVD disc cannot be decoded to have speaker output.
- This Unit is too hot, shut off the Unit for 30 minutes to cool down.
- You can use the Pink Noise setting to test that the speaker output is present (Please see Customizing the Function Settings)
- Make sure you turn on the power on the rear of the subwoofer.

Severe hum or noise is heard.

- · Check that the speakers and equipment are connected securely.
- Check that the connecting cords are away from a transformer or motor, and at least 10 feet (3 meters) away from a TV set or fluorescent light.
- Move your TV away from the audio equipment.
- The plugs and jacks are dirty. Wipe them with a cloth slightly moistened with alcohol.
- · Clean the disc.
- Vibrations from the speakers are affecting the Unit.

The remote does not function.

- Remove any obstacles between the remote and the Unit.
- Use the remote near the Unit.
- · Point the remote at the remote sensor on the Unit.
- Replace all the batteries in the remote with new ones.

The disc does not play.

- There is no disc inside ("No Disc" appears on the TV screen).
- Insert the disc correctly with the playback side facing down on the disc tray.
- · Clean the disc.
- A non-NTSC or PAL disc has been inserted. The Unit and disc region numbers are incompatible. Press the NTSC/PAL button on the remote to ouput the video signal.
- Condensation may have formed inside the Unit due to a sudden change in temperature. Wait about an hour for it to clear and try again.

The DVD door cannot open.

 Reset the Unit, press the POWER button to turn off the Unit, wait for a few seconds, then restart the Unit.

811-S15191-060











